



# U.V. PLUS

## NATURAL WOOD FINISH

**DESCRIPTION:** U.V. Plus is an oil based penetrating wood finish suitable for decks, log homes, wood siding, fencing and other exterior wood surfaces. UV Plus protects wood while maintaining a natural appearance.

### SPECIFICATIONS

#### VEHICLE TYPE

Solvent based, blend of linseed oils and alkyds

#### COLORS

Available in Natural, Natural Pine / Fir, Natural Cedar, Natural Redwood, Natural Sequoia, Navajo Red, Oxford Brown, Dark Walnut, Oak Brown, Driftwood Gray, Cape Cod Gray and Charcoal.

#### VISCOSITY

15-18 Seconds Zahn #2 at 77F

#### VOC CONTENT

MC-500 Series < 450 g/L (as supplied)  
 VOC MC-500 Series <250 g/L (as supplied)  
 MS-600 Series < 450 g/L (as supplied)  
 VOC MS-600 Series <250 g/L (as supplied)

#### SOLIDS BY VOLUME

MC-500 Series 45%  
 VOC MC-500 Series 62%  
 MS-600 Series 45%  
 VOC MS-600 Series 62%

#### SOLIDS BY WEIGHT

MC-500 Series 50%  
 VOC MC-500 Series 64%  
 MS-600 Series 50%  
 VOC MS-600 Series 64%

#### WEIGHT PER GALLON

7.3 to 7.9 Pounds

#### COVERAGE

Rough Wood: 100 to 150 square feet per gallon  
 Smooth Wood: 150 to 250 square feet per gallon

#### DRY TIME

Allow 24 hours in good drying conditions

#### APPLY WITH

Brush, roller, airless spray

#### PACKAGING

One gallon and five gallon containers. Quarts available in most colors.

#### SURFACE PREPARATION

Always clean gray or dirty wood before applying UV Plus. Use Messmer's WD Wood and Deck Renewer, available in liquid and powder concentrates. Allow wood to completely dry for at least 24 to 48 hours. Previously stained or treated wood should be sufficiently weathered to allow for complete penetration of U.V. Plus. New redwood should be aged at least 6-8 weeks and cleaned before applying product.

#### SPECIAL INSTRUCTIONS

Before applying, this product should be mixed thoroughly. Ensure that all settled material on bottom of can is evenly incorporated, and intermix all containers (box them).

Apply UV Plus when surface temperatures are between 45F and 90F. If surface is hot to the touch, it is too hot to apply product. Do not apply product if precipitation is expected within 24-48 hours.

Spray Application: When spraying, back brush or roll to prevent sags and runs. Cover surrounding areas to protect from overspray. For airless spray, use .015" to .019" tip size for best results.

Brush Application: To minimize lapping, maintain a wet edge lengthwise and do not break in the middle of boards.

**One coat is sufficient for most applications. Product not absorbed into the wood within 30-60 minutes must be removed to prevent surface sheen.**

#### THINNING RECOMMENDATIONS

Thinning is not recommended.

#### CLEANUP

Use paint thinner. Dispose of waste in accordance with local, state and federal regulations. **Danger - Rags, steel wool or waste soaked with UV Plus may spontaneously catch fire if improperly discarded. Immediately after each use, place rags, steel wool or waste in a sealed, water filled metal container.**