



# TIMBERFLEX

*ALASKAN LOG HOME FINISH*

**DESCRIPTION:** Timberflex is a premium oil based, film forming exterior wood finish. Timberflex remains flexible and UV light resistant even in extreme environments and is excellent for log homes and many other vertical exterior wood surfaces.

## SPECIFICATIONS

### VEHICLE TYPE

Solvent based, alkyd resins.

### COLORS / SHEEN LEVELS

Available in Natural, Natural Pine / Fir, Natural Cedar, Natural Redwood, Natural Sequoia, and other Messmer's colors by special order. Topcoat with Timberflex Exterior Clear Gloss or Timberflex Exterior Clear Satin to achieve desired sheen level.

### VISCOSITY

28-32 Seconds Zahn #2 at 77F

### VOC CONTENT

TF Series <350 g/L (as supplied)

### SOLIDS BY VOLUME

TF Series Clears and Colors 59%

### SOLIDS BY WEIGHT

TF Series Clears and Colors 62%

### WEIGHT PER GALLON

8.0 to 8.1 pounds

### COVERAGE

Rough Wood:	1st Coat:	125 to 150 sq. ft. / GL
	2nd Coat:	200 to 250 sq. ft. / GL
	3rd Coat:	300 to 400 sq. ft. / GL
Smooth Wood:	1st Coat:	150 to 200 sq. ft. / GL
	2nd Coat:	250 to 300 sq. ft. / GL
	3rd Coat:	300 to 400 sq. ft. / GL

### DRY TIME

Allow at least 24 hours between coats in good drying conditions.

### APPLY WITH

Brush, roller, airless spray

### PACKAGING

One gallon and five gallon containers

### SURFACE PREPARATION

Always clean gray or dirty wood before applying Timberflex. Use Messmer's WD Wood and Deck Renewer, available in liquid and powder concentrates. Allow wood to completely dry for at least 24 to 48 hours.

### SPECIAL INSTRUCTIONS

Before applying, this product should be mixed thoroughly. Ensure that all settled material on bottom of can is evenly incorporated, and intermix all containers (box them).

Apply Timberflex when surface temperatures are between 50F and 90F. If surface is hot to the touch, it is too hot to apply product. Do not apply product if precipitation is expected within 24-48 hours.

Spray Application: When spraying, back brush or roll to prevent sags and runs. Cover surrounding areas to protect from overspray. For airless spray, use .015" to .019" tip size for best results.

A total of three coats are recommended for new work in most applications. Begin with two color coats and follow with one clear coat of the desired gloss level. If stronger color is desired, use three color coats.

### RECOMMENDED MAINTENANCE

Additional maintenance coats should be applied every two to three years or as needed to maintain original appearance. Southern and western exposures may require more frequent applications.

### THINNING RECOMMENDATIONS

Thinning is not recommended.

### CLEANUP

Use paint thinner. Dispose of waste in accordance with local, state and federal regulations. **Danger - Rags, steel wool or waste soaked with Timberflex may spontaneously catch fire if improperly discarded. Immediately after each use, place rags, steel wool or waste in a sealed, water filled metal container.**